

540-0100 Standard e-PAD Operation and Features

The e-PAD is shipped with default *Authority* and *Access Codes*. If the OEM or dealer has not changed default codes, the *Authority* and *Access Codes* are:

Access code:

Digit 1	Digit 2	Digit 3	Digit 4	Digit 5
1 / 2	3 / 4	5 / 6	7 / 8	9 / 0

Authority code:

Digit 1	Digit 2	Digit 3	Digit 4	Digit 5
7 / 8	7 / 8	7 / 8	7 / 8	7 / 8



Lock Doors with Keypad

Press and hold down the (1 / 2) button for 1-2 seconds. An access code is not needed to lock the doors.

Using Secure Operations

Entering a valid 5-digit access code provides a double beep and enables a secure operation. After entering an access code, the keypad is enabled for 5 seconds and the next button pressed initiates a secure operation, such as unlocking the doors.

Notes:

- The authority code does not allow for secure operations. It is only used to assign access codes (see page 4 for information on setting authority and access codes).
- If an unassigned button or no button is pressed while the system is enabled, the keypad reverts back to disabled state.
- If keypad does not provide double beep, a valid access code has not been entered.

Available Secure Operations

Button (1 / 2): Unlock entry doors.

Button (3 / 4): Unlock doors wired to 2nd Unlock output.

Button (5 / 6): NA

Button (7 / 8): Sequentially activate entry unlock and 2nd unlock outputs.

Button (9 / 0): Toggle dome light output.