

# POLYDET® Care & Maintenance

## Guidelines for POLYDET® FRP panel products

### Maintaining Finish:

1. Wash your RV with liquid detergents.
2. If you prefer to wax the sidewalls, use automotive cleaner or waxes/polishes developed for use on fiberglass boats, showers and tubs. Follow the directions on the package.

### Restoring Gloss:

This is the procedure for restoring the gloss and finish to a weathered POLYDET® RV product. It is for hand application only.

### Materials needed:

- Mild detergent
- Soft cotton cloth
- Turtle Wax®\* Rubbing Compound Heavy Duty Cleaner
- Turtle Wax® Super Hard Shell Car Wax Paste
- Mechanical buffer (optional)
- Turtle Wax® Polishing Compound (for buffer use only)

(\*Turtle Wax is a registered trademark of Turtle Wax, Inc.)

1. Wash the POLYDET® panel with a mild detergent and water.
2. Dry the POLYDET® panel with a clean, soft cotton cloth.
3. Apply heavy duty cleaner by following the directions on the container.
4. Wash the POLYDET® panel with water and dry the surface.
5. Apply car wax paste per directions.

If a buffer is available, substitute polishing compound in Step 3 for heavy duty cleaner and buff polishing compound lightly. Then continue with Steps 4 and 5.

### **Note:**

POLYDET® panels do not have to be waxed, but should be washed regularly, to be covered under the warranty. Waxing will maintain the luster and beauty of the sidewall.