

# MORryde PATIO RAILING

## INSTRUCTIONS

### UNFOLDING

#### STEP 1

Undo the Velcro security straps that tie the patio gates together.

#### STEP 2

Starting with the curb side, swing the patio gate outward to the side of the ramp door.

#### STEP 3

Before swinging out the rear patio gate, ensure that the pin on the ramp door is captured by the bottom receptor on the gate.

#### STEP 4

Unfold the rear patio gate and lock into place with the foot activated latch. You will hear the latch click when secure.

#### STEP 5

Now do the same on the road side patio, and slide the door latch over the top of the patio to secure.

#### STEP 6

Ensure the blue safety bar and door latch on the top of the patio gate is locked.

### FOLDING

#### STEP 1

Undo the blue safety bars, door latch and foot latch.

#### STEP 2

Starting with the road side, fold the patio back up on itself and swing it back into the unit.

#### STEP 3

Now do the same with the curb side patio.

#### STEP 4

Once both patios are inside, reattach the Velcro straps for security when traveling.

## MAINTENANCE

### CLEAN

The railing can be wiped down with a damp cloth

### CARE

Periodically make sure bolted connections are tight.

Hinge pivot bolts should not be overtightened and allowed to freely pivot

Inspect casters to make sue they are tight to frame



Above. Beyond. Always.

574.293.1581 • [www.MORryde.com](http://www.MORryde.com)