

# Winter Shut-Down Procedures

**Important:** Filter Housings will break if water is left in them in freezing weather conditions.

---

*The following procedure is recommended if you are winterizing your RV.*

1. Shut off the water supply to the filter system.
  2. Relieve pressure from the water system by turning on cold water in shower and kitchen. Leave open during procedure.
  3. Remove the filter housing by turning counter clockwise.
  4. Slide out the old filter and discard. O-rings should be saved for future use.
  5. Empty excess water from the filter housing and reinstall by turning clockwise.
  6. Close cold water valves and proceed with winterizing the rv.
- 



# Winter Shut-Down Procedures

**Important:** Filter Housings will break if water is left in them in freezing weather conditions.

---

*The following procedure is recommended if you are winterizing your RV.*

1. Shut off the water supply to the filter system.
  2. Relieve pressure from the water system by turning on cold water in shower and kitchen. Leave open during procedure.
  3. Remove the filter housing by turning counter clockwise.
  4. Slide out the old filter and discard. O-rings should be saved for future use.
  5. Empty excess water from the filter housing and reinstall by turning clockwise.
  6. Close cold water valves and proceed with winterizing the rv.
- 

