

CAUTION!!!

DO NOT OVER TIGHTEN EZ READ TIRE CAPS

PLEASE FOLLOW INSTALLATION INSTRUCTIONS

Here is a link to a YouTube video that demonstrates how easy it is to install the EZ read Tire caps.

<https://www.youtube.com/watch?v=KeOxgqBt9aI>

(The EZ Read Tire Cap functions by monitoring your PSI – if you over tighten the tire stem will become fully depressed, resulting in a flat tire. Installation is quick and easy following simple instructions.)

INSTALLATION – Remove original tire cap – Place new EZ READ TIRE CAP on valve stem, turning clockwise ****ONLY HAND TIGHTEN UNTIL YOU HEAR THE AIR STOP HISSING OUT THEN TURN ONE HALF TURN MORE AND STOP**** - if you over tighten, air will leak out and your tire will go flat – Green is inflated properly.

Available in various PSI.

PSI50 Green 50PSI – will alert YELLOW at 38PSI (25%) – will alert RED at 35PSI (35%)

PSI65 Green 65PSI – will alert YELLOW at 49PSI (25%) – will alert RED at 46PSI (35%)

PSI80 Green 80PSI – will alert YELLOW at 60PSI (25%) – will alert RED at 52PSI (35%)

PSI110 Green 110PSI – will alert YELLOW at 83PSI (25%) – will alert RED at 72PSI (35%)

WARRANTY

This product has a warranty to be free of manufacturing defects for a period of one year from date of purchase. If found to be defective, please return the product with dated proof of purchase for immediate replacement.

CLC International Inc.
202 S Main St
Nappanee, IN 46550
574 773 9000
574 265 6610
kkeeling@clcinternationalinc.com
www.clcinternationalinc.com

June 2020