
- NOTICE:

 * We are committed to developing new products.

 * We reserve the right to change the design and specification of our products without any prior notice.



INSTRUCTION MANUAL



DVD1000

DIRECTORY

| APP CONNECT FOR APPLE (ios10.3.3)——— 14~15 | | SPEAKER WIRING | INTERFACE SPECIFICATION | BOTTOM PANEL 7 | FRONT PANEL 4~6 | INTERFACE SPECIFICATION3 | MATTERS NEEDING ATTENTION | IMPORTANT SAFETY INSTRUCTIONS ——— 1 |
|--|--|----------------|-------------------------|----------------|-----------------|--------------------------|---------------------------|-------------------------------------|
|--|--|----------------|-------------------------|----------------|-----------------|--------------------------|---------------------------|-------------------------------------|


IMPORTANT SAFETY INSTRUCTIONS



CAUTION RISKOF ELECTRICS DO NOT OPEN



CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER(OR BACK). NO USER-SERVICING TO QUALIFIED SERVICE PERSONNEL.



The lighting flash with arrowhead symbol within an equilateral triangle is intended to alert the user to the presence of uninsulated?dangerous voltage? within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.

appliance.

instructions in the literature accompanying the

is intended to alert the user to the presence of important operating and maintenance (servicing)

FCC WARNING

To assure continued compliance, follow the attached installation instructions and use only shielded cables when connecting to other devices. Modifications not authorized by the manufacturer may void user's authority to operate this device.

MATTERS NEEDING ATTENTION

performance is good, please read carefully and must obey; Users in order to correctly use media player to ensure players

- 1: Please read manual carefully before handling the system.
- 2?Don't seriously impact the host
- 3?Do not contact with benzene, thinner, chemicals, etc.
- 4?Please don't get close to strong magnetic field, electric field.
- 6? Don't open the cover in order to avoid shocking and 5?Please avoid direct light or heating apparatus.
- 7?Don't use loud volume to listen to, in order to avoid bad damage to hearing.

damage the machine.

Functional features

- 1:Bluetooth receives largest distance of 10 meters
- 2:Play MP3/mp4 format file in USB directly.
- 3:FM stereo radio receiver function
- 4:Stereo audio input interface, easy to connect computer, digital music player, mobile phone and other audio equipment.
- 5:App/Apk connect control
- 6:4 CH amplifier output.
- 7:Infrared remote control.
- 8:Wide range performance
- 9:AUX input.
- 10:CD player.
- 11:channel 2 video output
- 12:NFC function.

INTERFACE SPECIFICATION


\$ THE FRONT PANEL 0 (3)

- In FM mode, the key FM NEXT search key.
 In FM mode, the key FM BACK search key.

- In USB mode, the @ key USB pause/play button. In USB mode, the @ key USB the next song. In USB mode, the @ key USB the previous song.
- In disc mode, the 6 In disc mode the 🔞 key Disc the next and fast forward. key Disc the back and fast backard

FRONT PANEL

FM OF FRONT PANEL



Fast backward or last song
USB and FM TUNERNext song or fast forward
USB and FM TUNER+

00


Power on/off

Source

Press the SOURCE key, switch to the FM mode In FM mode, the O press by fine-tuning for Frequency point selection key.

frequency+.
In FM mode, the **©** press by fine-tuning for

AM OF FRONT PANEL



Press the SOURCE key, switch to the AM mode

Past backward or last song USB and Radio TUNERNext song or fast forward USB and Radio TUNER+

Power on/offSource


Press the SOURCE key, switch to the AM mode Frequency point selection key. 📵 FM/AM Selet

In AM mode, the O press by fine-tuning for

In AM mode, the @ press by fine-tuning for

FRONT PANEL

BLUETOOTH OF FRONT PANEL



Pick up the phone key.

Bluetooth music play/pause key. Hang up the phone key.


Press the . SOURCE key, switch to the BT mode

1:Open the settings in mobile phone,
2:Open the BT in the setup.
3:Automatic search in the BT, appear DVD1000 device name.
4: DVD1000 device name, connection.
5:After the connection is successful, the speaker tip is connected to the DVD1000 device.

6: When disconnected, speakers tip has been disconnected.

7:Connect the NFC sensing area of the phone to the NFC area and the system will automatically connect

DVD/USB OF FRONT PANEL



Press the SOURCE key, switch to the DISC/USB mode

Play/puase

S Fast backward or last song

Next song or fast forward


Stop Stop

In the USB and DISC mode


BOTTOM PANEL

VIDEO OUTPUT IN DISC/USB MODE


AUX OF FRONT PANEL



Press the SOURCE key, switch to the AUX mode AUX input, L+R 2 channel.







SYSTEM RESET

MIC INPUT

B EARPHONE(L+R)

IN and OUT of the disc




VIDEO OUT1

VIDEO OUT2


<u>-</u>


Tv2



INTERFACE SPECIFICATION


REAR PANEL





REAR PANEL

INTERFACE SPECIFICATION



S ACC

8 8

N C Z C N C Z C

0 0 0 0 0 8 3

FUSE N_C

10A/12V

N O N C R-OUT B-ZONE

R-OUT A-ZONE R+OUT A-ZONE

ANT

R+OUT B-ZONE

DC12/10A GND

L+OUT A-ZONE L-OUT A-ZONE

0

L+OUT B-ZONE L-OUT B-ZONE

SPEAKER(6*40HMS) WIRING COLOR CODE GUIDE

| CAUTION! Connectiong the speakers incorrectly will cause distortion and damage the power amplifier |
|--|

Drive()

TITLE

В


SUBTITLE

C

D

SETUP

VOL+



orange/-A-ZONE L+
Green/-B-ZONE L+
orange/black-A-ZONE LGreen/black-B-ZONE LPink/-A-ZONE R+
White/-B-ZONE R+
Pink/Black-A-ZONE RPURPLE-ANT
White/black-2-ZONE RBLACK-GND

NC CONNEC.

Last song or up(in disc)

≱ lot

Next song or down(in disc)

VOLUME+

POWER ON/OFF

Backard fast or left

Language switching

Bass+ adjust Bass- adjust

▼ DOWN

UP

Treble+ adjust

when. Right(tuner+ in radio mode)

Left(tuner- in radio mode)

Numeral key

OK Enter key
REP repeat key

泵

MUTE

-

NC CONNECT
yello-DC/12V/10A

NC CONNECT

Subtitle

10

Stop of the Disc

ANGLE/NUMERAL 10+

In or out the disc

1-ZONE MUTE C-ZONE MUTE

2 -ZONE MUTE

Forward fast or right PAUSE/PLAY


SOURCE

MOBILE PHONE CONNECTION WITH BLUETOOTH

Ŧ(0)

Enable Cloud backup
Hack up attravelleting rectives any tenso

Enable Account protection tradeque Markett Discount records



* DVD1000

Printing

[] iPhone

Θ

Mulli-screen

NFC
Alban data excludes when the phane tracken another device.

Device name
Received files
PAIRED DEVICES

0

Storage
Wenner, Storage cleaner

Butter
 Butter
 Butter
 Butter
 Butter
 Supplies
 Sound
 Sound
 Committee and display Vision

Windess & networks

What back staf working, in delive deal

Control back staf working, in delive deal

Control back staff working

Apps & notifications

Framerisers Delayer spen, septuals

Security & privacy

Pagespear is Serven high 5 preserved a

0


checked and connect

10


₹**⊙**


20

APK CONNECT FOR ANDROID



INSTALLATION DIMENSIONS AND ACCESSORIES





| cable | ver | |
|-------|----------------|--|
| | Atti-sutton la | |

Screws*4pcs

TECHNICAL SPECIFICATIONS

Working voltage: DC12/10A The output power?60W

Signal to noise ratio: 80dBA Frequency response:35HZ~20KHZ

Size: 200mm(L)*175mm(W)*110mm(H) The input sensitivity: 450+50mA

о А