


Quick Start Guide

32 LED TV

SE32HY

Remote Control



Remote Control Set Up



Remove the battery compartment cover.




Insert 2xAAA batteries with correct polarity (+/-) as indicated.



Replace the cover.

Front View



Connecting to Your TV

Installing the Stand

