




DW-BT-MAG1 RV Speaker

User's Guide



DW-BT-MAG1

Each part button




Key operation instructions

Button	Name	Function Description
	Power button	- Power on: Press and hold for 2S to power on. It will enter Bluetooth pairing mode by default. - Power off: Press and hold for 2S to power off. - Pause/Play: Click to play/pause.
	Pairing TWS LED mode Reset	- Connect: Double-click to enter TWS pairing mode. When pairing is in progress, the RGB light flashes blue. The connection is successful. The blue light stays on. If there is no pairing within 60S, the TWS mode will be automatically exited. - Disconnect: Double-click to exit TWS mode. - Lighting effect: Click to cycle through RGB (Colorful Transformation-Colorful Breathing-Colorful Rotation-Purple-Light Blue-Yellow-Run off the light). The last lighting effect is disabled when turned on. - Reset: Press and hold for 5S to restore factory settings.
	Volume -	Volume reduction: Click to reduce the volume, click continuously to quickly reduce the volume.
	Next song	Next song: Press and hold for 2S to next song.
	Volume +	Volume increase: short press to increase volume, long press to quickly increase volume.
	Previous song	Previous song: Long press 2S to go to the previous song.

Button	Name	Function Description
	Speaker indicator light	- Wireless charging: the green light is always on, foreign object detection: the red light is always on. - Speaker charging: The blue light stays on during charging, and turns off when the battery is fully charged.
	Speaker charging port	The speaker is charging. When charging, the blue light is always on, and when fully charged, the light goes off.
	Base charging port	Speaker charging: When charging, the blue light is always on, and when fully charged, the light goes off.

Bluetooth pairing

1. Bluetooth connection: Open the Bluetooth interface of the mobile phone, search for the Bluetooth name DW-BT-MAG1 and click to connect.
2. Tip: If you cannot find the Bluetooth name, please press and hold the for 5 seconds. After the Speaker is reset, search for Bluetooth again to connect.



Power on: Press and hold for 2S to power on. It will enter Bluetooth pairing mode by default.

TWS Function

Two speakers are close to each other. After turning on the phone, without connecting to Bluetooth, double-click the "pairing button" of one of the speakers for 2 seconds and wait for about 10 seconds. The two speakers will automatically pair. Open the Bluetooth interface of the mobile phone and search for "DW-BT-MAG1", click Connect, the connection is successful, and the two speakers can play songs at the same time.

Speaker charging


1. Connect the DC5V power supply to the Type-C charging port of the Speaker for charging. 2. Place the speaker on the charging base, connect the DC5V power supply to the Type-C charging port of the base, or connect the base power cord to the 12V power supply for charging. Tip: During charging, the blue light on the Speaker is always on, and when fully charged, the light turns off.



The speaker is placed on the charging base to charge.

Wireless charging

1. Wireless output 5W Max.
2. For mobile phones that support wireless charging, place them in the wireless charging sensing area to charge the phone.
3. Tip: When the power supply is not connected, playing songs while charging the phone will consume power very quickly. The battery can only last for about an hour. It is recommended to connect to the power supply before charging the phone. When the speaker runs out of power, it will not be able to charge the mobile phone. The speaker needs to be fully charged or connected to a power source before the wireless charging output can be used to charge the mobile phone.




Wireless charging

Power saving mode

Charging: The blue light is always on during charging, and turns off when the battery is fully charged. The charging port of the base is connected to the Type-C charger. The base is connected to the power supply, and the Speaker is charged. During charging, the blue light is always on, and the light goes off when the battery is fully charged.

Magnetic fixation

There are built-in magnets on both sides of the bottom, which can be attached to golf carts or other iron materials to play music. Tip: Please do not attach to dangerous objects, such as electrical boxes, to avoid causing personal injury or damaging the speaker.



Position of magnet

Product parameters

Model	DW-BT-MAG1	Bluetooth version	5.3
Rated power	20W	Charging time	2.5H
Play time	12H (80% volume)	Product size	200*75*35mm
Battery capacity	2200mAh/74Wh	Wireless charging output	5W Max.
Water proof level	IPX5	Charging voltage	DC 5V/DC 12V (charging base)
Support	A2DP V1.3, AVRCP V1.6, TWS		
Functions	Bluetooth music, TWS interconnection, 5W wireless charging magnetic fixation		

Note

1. Please read the instructions carefully and use the product according to the operating instructions.
2. Please use or store this product in a room temperature environment.
3. Do not use this product close to heat sources, such as radiators, heaters or other heating instruments.
4. In order to protect your hearing and extend the service life of the product, please do not turn the volume down for a long time.
5. Adjust to medium.
6. Please choose a charger that has passed the safety certification of a regular manufacturer to charge the product.
7. It is recommended to fully charge the product before using it for the first time. If you have not used the product for a long time, please
8. Fully charge the product every 3 months to avoid battery damage.