


REFRIGERATOR **Instruction Manual**



CONTENTS

4 Trouble shooting · · · · · · · ·	3.2 Clean the refrigerator · · · · · ·	3.2 Stop using the refrigerator · · · · ·	3.1 Disconnect the refrigerator · · · · ·	3 Maintenance of refrigerator	2.6 Energy saving tips · · · · · · · · · · · ·	2.5 Start to use · · · · · · · · ·	2.4 Placement · · · · · · · · · · · · · · · · · · ·	2.3 Move · · · · · · · · · · · · · ·	2.2 Temperature Control · · · · · · · · ·	2.1 Names of components · · · · · · · · ·	2 Proper use of refrigerator	1.6 Warnings related to disposal · · · · · · ·	1.5 Warnings related to placing items · · · · ·	1.4 Related warnings for use · · · · · ·	1.3 Electricity related warnings · · · · · · ·	1.2 Meaning of safety warning symbols · · ·	1.1 Warning	1 Safety warnings
	٠	٠	•		:		•	•	•	•		•	•	:	:		•	
•	•	•			•		•	Ċ	•	:		:	:		•	٠	•	
•	•	:			:	•						•	•	•	:	•	•	
•						٠	•	•		•		•	•	•		Ţ		
•					٠	٠	•	٠	•	:		:	:	•	•			
:					:	•	:	•	•			•		•	:	٠	•	
•		•	•			•	•			٠		•	•			٠	•	
•	•		•		٠	٠	•		Ċ	•		•	•		•	:	•	
:	•	•	•		•	٠	:			:		:	:		:		٠	
	•	٠	•		:	•											٠	
•	•	•	•		•	•	•	•	•			:	•	•			٠	
ω	7	7	7		σ	თ	ത	O	Οī	O		4	4	ω	N	N		

DEAR CUSTOMER:
Thank you for buying this refrigerator. To ensure that you get the best results from your new refrigerator, please take time to read through the simple instructions in this booklet. Please ensure that the packing material is disposed of in accordance with the current environmental requirements.

When disposing of any refrigerator equipment please contact your local waste disposal when disposing of any refrigerator equipment please contact your local waste disposal. This appliance must be only used for its intended purpose.

1 Safety warnings

1.1 Warning



Warnning:risk of fire / flammable materials

bed and breakfast type environments; farm houses and by clients in hotels, motels and other residential type environments staff kitchen areas in shops, offices and other working environments; RECOMMENDATIONS:

This appliance is intended to be used in household and similar applications such as

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given catering and similar non-retail applications.

Children should be supervised to ensure that they do not play with the appliance

supervision or instruction concerning use of the appliance by a person responsible for their safety

If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard

Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance. The appliance has to be unplugged after use and before carrying out user maintenance on the applia carrying out user maintenance on the appliance.

WARNING: Risk of fire / flammable materials.

WARNING: Keep ventilation openings, in the appliance enclosure or in the built-in structure, clear of

WARNING: Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer.

WARNING: Do not damage the refrigerant circuit.

they are of the type recommended by the manufacturer. WARNING: Do not use electrical appliances inside the food storage compartments of the appliance, unless

WARNING: Please abandon the refrigerator according to local regulators for it use flammable blowing gas and refrigerant.

Do not use extension cords or ungrounded (two prong) adapters DANGER: Risk of child entrapment. Before you throw away your old refrigerator :

Take off the doors

-Leave the shelves in place so that children may not easily climb inside

The refrigerator must be disconnected from the source of electrical supply before attempting the installation

Refrigerant and cyclopentane foaming material used for the refrigerator are flammable.

Therefore, when the refrigerator is scraped, it shall be kept away from any fire source and be recovered by a special recovering company with corresponding qualification other than be disposed by combustion, so as to prevent damage to the environment or any other harm.

1.2 Meaning of safety warning symbols



the personal safety of users. behaviors are forbidden. Non-compliance with the The symbols indicate prohibited matters, and those instructions may result in product damages or endanger




The symbols indicate matters that must be followed, and those behaviors must be strictly executed in line with the operation requirements. Non-compliance with the the personal safety of users. instructions may result in product damages or endanger




these behaviors shall be specially noted. Due or damages of the product will be caused precautions are needed or minor or moderate injuries The symbols indicate matters to pay attention to, and

This manual contains lots of important safety information which shall be observed by the users.

.3 Electricity related warnings



- Do not pull the power cord when pulling the power plug of the the commercial refrigerator. Please firmly grasp the plug and pull out it from the socket directly.
- Do not damage the power cord under any condition so as to ensure safety use, do not use when the power cord is damaged or the plug is worn.
- Worn or damaged power cord shall be replaced in manufacture-authorized maintenance stations.



a

Please uso a dedicated three-hole power socket which is 15A or more and the power socket shall not be shared with other electrical appliances. The power plug should be firmly contacted with the socket or clso fires

power socket is equipped with a reliable grounding line. might be caused. Please ensure that the grounding electrode of the




Please turn off the valve of the leaking gas and then open the doors and windows
in case of leakage of gas and other flammable gases. Do not unplug the commercial
refrigerator and other electrical appliances considering that spork may cause a fire.



0


To ensure safety, it is not recommended that to place regulators, rice cookers, microwave events and other appliances at the top of the the orifigerator, those recommended by the annufacture are not included. Do not use electrical appliances in the food panity.

1.4 Related warnings for use




- Do not arbitrarily disassemble or reconstruct the cooler, nor
- damage the refrigerant circuit; maintenance of the appliance must be conducted by a specialist.


 Damaged power cord must be replaced by the manufacturer, its maintenance department or related professionals in order to avoid danger.



- The surrounding of the appliances around or the embedded structure shall not be obstructed while good ventilation shall be maintained.
 The gaps between refrigerator doors and commercial refrigerator body are small, be noted not to put your wet hands hand in these areas to prevent squeezing the finger. Please be gentle when switching off the refrigerator door to avoid falling articles.



Do not allow children to enter or climb the refrigerator to prevent that children are sealed in the refrigerator or children are injured by the falling refrigerator.




ø


- Do not place heavy objects on the top of the refrigerator considering that objectives may fall when switching the door, and accidental injuries might be caused.
- Please pull of the plug in case of power failure or cleaning. Do not connect the refrigerator to power supply within five minutes to prevent damages to the compressor due to successive starts.

ω

1.5 Warnings related to placing items



- Do not put flammable, explosive, votatile and highly corrosive items in the refrigerator to prevent damages to the product or fire accidents.
- Do not place flammable items near the refrigerator to avoid fires.



This product is refrigarator and shall be only suitable for the storage of foods and drinks. According to national standards, refrigorators shall not be used for other purposes, such as storage of blood, drugs or biological products.

0


1.6 Warnings related to disposal



The refrigerator contains small amount of environmental friendly refrigerant and centains air in insulating layer. The refrigerant and air shall be processed specialized, Do not break refrigerant loop before specialized processing.


2 Proper use of refrigerator

2.1 Names of components




The refrigerator you buy some of the features and accessories may be entirely consistent with the legend, pleaserefor to the object.

2.2 Temperature Control




After the refrigerator has been turned on, turn the temperature control knob to adjust the level of temperature controller. Setting the control to cold is the warmest setting. Setting the control to colder is the coldest setting. Moving the control to OFF stops cooling.

2.3 Move



For short distance and adjust position, the refrigerator can be moved by two wheels in the rear. It is prohibited from long distance and uneven ground pushment.

2.4 Placement




remove all packaging materials including bottom cushions and foam pad sand tapes inside the refrigerator, tear off the protective film on the deer and the refrigerator body. efrigerator,




The refrigorator is placed in a welf-ventilated indoor place; the ground shall be flat, and sturdy (rotate left or right to adjust the wheel for toveling if unstable).




 Keep away from heat and avoid direct sunlight. Do watery places to prevent refrigerator in moist or not place the commercial rust or reduction of



insulating offoct.



The hot air from side wall of compressor's power will increase and further increase power exhausted unrestricted, or refrigerator shall be and walls or neighboring furniture between retrigerator consumption. Thus the distance




shall not less than 4cm.

833mm

0 0

Dimensions shown are for reference only.



The refrigerator shall stay for half an hour before connecting power when it is firstly started.

The refrigerator shall run 2 to 3 hours before loading drinks: the refrigerator shall run for more than 4 hours in summer in advance considering that the ambient temperature is high.

2.6 Energy Conservation

- The refrigerator shall be placed in room dry and ventilated. The refrigerator cannot be put under direct sunlight or next to hear source (Such as radiator, stove, etc.), and a suitable insulation board shall be applied if necessary.
- Try to shorten opening time of refrigerator's door.
 © Put foods, beverages into refrigerator after it has cooled down.

U

3 Proper use of refrigerator

3.1Disconnect the refrigerator


Unplug power plug to disconnect the refrigerator.

3.2 Stop using the refrigerator


If the refrigerator toft unused for a long time, please:
1. Unplug the refrigerator;
2. Clean the orfrigerator;
3. Keep the refrigerator door open.

3.3 Clean the refrigerator

Dusts behind the refrigerator and on the ground shall be timely cleaned to improve the cooling effect and energy saving. The interior of the refrigerator should be cleaned regularly to avoid odor. Cleaning procedure



1.Unplug power plug or disconnect cutoff:
2.Clean door seal with only clear water and give thorough wipe:
3.Reconnect and power refrigerator when cleaning is completed.



0

- O not use hard brushes, clean steel balls, wire brushes, abrasives, such as teethpastes, organic selvents (such as alcohol, acetone, banana ell, etc.), belling water, acid or alkaline items clean therefrigerator considering that this may damage therefrigerator surface and interior.
- Do not rinse with water so as not to affect the electrical insulation properties.
- Do not use detergent and solvent with sand or acid.
 The drain hole shall be cleaned regularly to ensure water can be drained.
 Clean the drain hole with a thin stick or something similar.

4 Trouble shooting

Normal noises

Buzzing-Tho refrigerating units are working.
Grunt, rumble or gurgle-Rofrigerating fluid is flowing in pipeline.

Noises that can be removed easily

Unsteady location of refrigerator:
Use gradienter to coordinate the refrigerator into smooth level. Can use thread support arm or put cushion under it.

The refrigerator leans against other furniture: Move refrigerator away from furniture or equipment it leans against.

Centainers contact with each other: Separate bottles or containers slightly.

Small trouble shooting by yourself.

Before calling after-sale service: Please examine to find out whether you can perform trouble shooting by yourself following under prompts.

Fault	Possible Causes	Remedies
Tomparatura has big doviation with set tomparature		Yurn off rofigorator's power for 5 minutes can as ametimes reacht. If temperature is too high, examine after several to find out whother temperature rotum to set value to low, rochock the lemperature is too low, rochock the lemperature is too low, rochock the
rofrigerator not cool down inside	Frequently open of commercial ratingerator's door. Too much bottlos input.	Reduce open frequency of commercial refrigerator. Walt for 4-5 hours.
nofrigerator not rofrigerato	roʻrigorator powor off or blackout; cutoff disconnoct; attaching plug looso	Prass switch button; chock whother power is on, chock cutoff.

œ